

Third Break Light Kit

- 1) Attach round bracket to tire mount plate with raised edges facing out.
- 2) Clip ends from OEM wiring. Expose some wire on the clipped ends and insert into round end of electrical connectors. Use either both male or female on the OEM wires and the other set on the pigtail wires. Crimp to secure wires in the connectors and ensure electrical contact.
- 3) Connect the OEM wire to the pigtail wire with the slide connectors.
- 4) Press the pigtail into the back of the light and test. If the light doesn't turn on when the brakes are pressed, the wires may need to be switched.
- 5) Secure the light by twisting it into the metal ring so the plastic ridges look into the rise of the metal bracket
- 6) If it is too loose, gently tap rise on the metal ring to create a tighter fit.

Part Number: JK-3BLK



Expedition One, LLC

113 N 700 W Bldg 5C Bay 1

Ogden, UT 84404

801.627.2921

www.exp-one.com

[Ex1 on Facebook](#)

[YouTube Expedition1TV](#)