

# INSTALLATION GUIDE

FJ Cruiser Rock Guards





# CONTENTS

FJ Cruiser Rock Guards Install. .... 3

### Disclaimer

Expedition One is not responsible for any damages to vehicle.  
We always recommend professional assistance when  
installing our vehicle products.

Included Hardware

- (2) Expedition One Sliders
- (16) Large Flat Washers
- (8) 3/8" Button Head Bolts
  - (8) 3/8" Nyloc Nuts
  - (16) M8 Metric Bolts

Needed Tools

- Socket Set / Metric
- Metric Wrenches
- Allen Wrenches

## Installation

Remove the forward most break line attachment on the frame.

Break line will rest on top of rear mount of slider after install is complete.



Lift the first slider and mount using the existing mounting holes in the frame and the 8 of the supplied M8 bolts and 8 flat washers.

DO NOT FULLY TIGHTEN until all bolts are in place and threading into the frame. Once all bolts are in place tighten until snug.

Torque specs if so desired: 10-20 foot pounds

DO NOT exceed 24 foot pounds of torque!!



Repeat steps 1 & 2 on opposite side to install 2nd rock slider.

