

INSTALLATION GUIDE

Pre-Runner Tire Mount Kit





CONTENTS

Pre-Runner Tire Mount Install 4

Disclaimer

Expedition One is not responsible for any damages to vehicle.
We always recommend professional assistance when
installing our vehicle products.

Included Hardware:

Two-Piece Tire mount bracket (Based on vehicle application)

(6) 1/2" Bolts

(12) 1/2" Washers

(6) 1/2" Nyloc Nuts

Tools:

3/4" Socket & Wrench

Skill Level:

2/5 stars (Professional install recommended)

Place Bottom support into position as shown below.



Attach 1/2" Bolts, washers and nuts as shown in photo.



Begin tightening all bolts shown in photo below.



Attach tire mount bracket to desired position on front of mount



Secure with provided 3/8" bolts, washers and nuts



Tighten down all bolts with 9/16" socket wrench





TIRE MOUNT

Not shown is mounting to bed of truck. There are various ways of doing this step.

Some customers prefer to drill into the bed and running bolts through the bottom.

Other methods include mounting rails to the bed and securing our pre-runner mount to the rails.

Any further questions, feel free to email us at info@expeditionone.biz