

INSTALLATION GUIDE

Charcoal Cannister Skid





CONTENTS

Charcoal Cannister Skid Install 3

Disclaimer

Expedition One is not responsible for any damages to vehicle.
We always recommend professional assistance when
installing our vehicle products.

Included Hardware:

2011 or below models use existing canister bolts

Below items are for 2012+

- (4) 3/8" button head bolts
- (4) 3/8" washers
- (4) 3/8" locking nuts
- (2) 5/16" hex bolts
- (4) 5/16" washers
- (2) 5/16" locking nuts

Tools:

5/8" socket wrench

2012+ tools listed below

- 13mm socket wrench
- 7/32" allen wrench
- 9/16" socket wrench

Skill Level:

1/5 stars

*Note - This part of install is for 2011 and older models

First, disconnect wiring from the charcoal canister under the vehicle.



Shown to right is the removal of hose lines on back of canister.



Remove rear mounting bolt shown to right.



Remove the two front mounting bolts and drop canister out of place.



Lay canister skid on flat surface and drop/maneuver canister into place as shown below.



Carefully place canister/skid back into position under the vehicle, reattaching the stock bolts and securing tightly.



Re plug and attach your electric wire(s) and hose back into canister.



*Note - This part of install is for 2012+ and newer models

First, disconnect wiring from the charcoal canister under the vehicle.



Shown to right is the removal of hose lines on back of canister.



Remove rear mounting bolt shown to right.



Remove the two front mounting bolts and drop canister out of place.



After removing bolts, remove canister from under the vehicle and place on a flat surface to work on.



Using a 13mm socket and wrench, undo the bolt at the back of the canister.



Remove canister from mounting bracket shown at right.



Screw on bracket with nut, bolts and washers as shown in photo to the right making sure they are loose.



Slide bracket over canister



Attach the smaller bracket on the bottom of canister as shown with nut, bolt and washers. You may now tighten these bolts down securely.



Slide your canister into the charcoal canister skid as shown



Use button head bolts, washers and nuts provided to secure into place.



This is the finished look before it gets mounted to vehicle.



Carefully place canister/skid back into position under the vehicle, reattaching the stock bolts and securing tightly.



Re plug and attach your electric wire(s) and hose back into canister.

