

INSTALLATION GUIDE

Mule Swing Arm Jack Mount





CONTENTS

Mule Swing Arm Jack Mount..... 3

Disclaimer

Expedition One is not responsible for any damages to vehicle.
We always recommend professional assistance when
installing our vehicle products.

Included Hardware:

- (3) 3/8" Button Head Bolts
- (3) 3/8" Washers
- (3) 3/8" Locking Nuts

Tools:

- 9/16" Socket or Wrench
- 7/32" Allen Wrench

Skill Level:

1/5 stars

Place back bracket around back side of arm as shown to right. Use two 3/8" bolts, washers and locking nuts to secure the bracket on the arm with the jack mount.



Use the last bolt, nut and washer and place through the top hole as shown in photo.



Shown below is the final look with the three bolts secured into place.

