

# INSTALLATION GUIDE

14+ Tundra Transmission Case Skid





# CONTENTS

14+ Tundra Transmission Skid Install .....4

Disclaimer

Expedition One is not responsible for any damages to vehicle.  
We always recommend professional assistance when  
installing our vehicle products.

Included Hardware:

- (2) 3/8 Bolts
- (4) 3/8" Washers
- (2) 3/8" nylon locking nuts

Tools:

- 15mm Socket/wrench
- 9/16" Socket/wrench

Skill Level:

1/5 stars (Professional install always recommended)

Remove Stock OEM REAR engine skid bolts as shown to the right.



Slide in the new transmission skid in between frame and existing OEM skid.



Using provided 3/8" bolts, run them through skids and frame, attaching the washer and nut on back side. Make sure to keep fairly loose for now until all bolts are in place.





Reattach stock bolts as shown in photo



Go ahead and tighten down all bolts securely and your all done!

